
MEET YOUR FIRE TV CUBE





POSITION YOUR FIRE TV CUBE



PLACE FIRE TV CUBE 30-60 CM AWAY FROM ANY SPEAKERS,

with the ports facing away from you.

IT SHOULD NOT BE PLACED IN A CLOSED CABINET.

Fire TV Cube needs to hear your commands.

To control components that are in a closed cabinet, use an IR extender (sold separately).

CONNECT YOUR FIRE TV CUBE





PLUG IN POWER CABLE

Connect the included power adaptor to Fire TV Cube and plug it into an outlet-socket.



2 CONNECT THE HDMI CABLE

Use a high-speed HDMI cable (not included) to connect the HDMI OUT port on the Fire TV Cube to HDMI port on your TV.



3 SELECT INPUT

Turn on your TV, then select the input on your TV that matches the name of the HDMI port you are connected to.

TIP: Using the included remote control, go to the Settings menu in Fire TV Cube, and select your network from the list displayed. If your network is hidden, enter your network name.

TIP: If you see a lock icon, your Wi-Fi network requires a password, so make sure you have it available. This password is not your Amazon account password.

For more troubleshooting and information, go to www.amazon.com/devicesupport.

LEARN ABOUT THE BUTTONS







MICROPHONE ON/OFF

Press the microphone on/off button to mute.





Control the internal speaker of Fire TV Cube.

FIRE TV ALEXA VOICE REMOTE



POWER UP YOUR REMOTE

INSERT BATTERIES

Use your thumbs to slide open the back of remote, then insert the included batteries.

Tip: If remote battery compartment will not open, clean backing with a moist cloth and dry thoroughly.



2 USE YOUR REMOTE

The remote can now control Fire TV Cube. To control other devices, follow the on-screen steps.

Tip: If remote isn't discovered, press and hold Home

button until the LED flashes amber.

WATCH WITH ALEXA

Alexa makes it easy to find, launch and control content. Simply say "Alexa" to Fire TV Cube or press the voice button on your remote.



DO EVEN MORE WITH ALEXA

Alexa can help you unwind, control your smart home devices, and keep you better informed, organised and connected.



ENHANCE YOUR EXPERIENCE

ETHERNET CABLE

If you prefer a wired Ethernet connection instead of Wi-Fi, please connect the Ethernet cable (not included) to the network port.

D EVTENDED

If you are using an IR extender (sold separately) to control devices in a closed cabinet, place the IR extender on the same shelf as the devices you want to control.

CABLE/SATELLITE BOXES

You can connect your Cable/Satellite set-top box, Gaming console or DVD/Blu-Ray player to the HDMI input port to easily switch input using Alexa and view content from these devices.

ALEXA HOME CINEMA

For an immersive audio experience, wirelessly pair your Fire TV Cube with compatible Echo devices. To learn more, go to www.amazon.co.uk/help/firetv/alexa-home-theater.

IDEO CALLING

Connect a compatible USB webcam to make two-way video calls. To learn more, go to https://www.amazon.co.uk/help/firetv/twowaycalling/qsg.

PRIVACY CONTROL



PRIVACY CONTROL

- \bullet Turn the mics off by pressing the microphone on/off button.
- See when Alexa is recording and sending your request to Amazon's secure cloud via the blue indicator light.



MANAGE YOUR VOICE HISTORY

You can view, hear and delete the recordings associated with your account in the Alexa app at any time.

To delete your voice recordings, say

- "Alexa, delete what I just said."
- "Alexa, delete everything I've ever said."

©2022 Amazon.com, Inc. or its affiliates. Amazon, Fire and all related marks are trademarks of Amazon.com, Inc. or its affiliates. Dolby, Dolby Vision, Dolby Audio, Dolby Atmos and the double–D symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992–2022 Dolby Laboratories. All rights reserved

ACCESSIBILITY



If you need help with accessibility, go to: www.amazon.co.uk/help/firetv/accessibility

